



Switches





| Web | Item Number | Description |
|---|--------------|-----------------------|
| | M SW-4JOY | 4-POSITION JOYSTICK |
|  | M SW 1TL1-1 | CENTERED SPDT NONLOCK |
| | M SW 1TL1-1A | SPDT CENTERED |



| Web | Item Number | Description |
|--|--------------|------------------------------|
|  | M SW 1NT1-2 | SPST ONE-POLE ON-OFF |
| | M SW 1NL1-2D | SPST, BOTH POSITIONS LOCKOUT |
| | M SW 1NT1-3F | SPST, ONE-POSITION LOCKOUT |



| Web | Item Number | Description |
|---|---------------|---------------------------|
|  | M SW 1NT1-6 | SPST MOMENTARY |
|  | M SW 1NT1-7 | SPDT CENTERED MOMENTARY |
| | M SW 4NT1-12A | DPDT, 3 POSITIONS LOCKOUT |



| | | |
|--|-----------------|-----------------------------|
| | M SW N1030-2501 | GRAY SILICON SWITCH COVER |
| | M SW N1030-2503 | YELLOW SILICON SWITCH COVER |
| | M SW N1030-2508 | RED SILICON SWITCH COVER |